



MASH 2016 TL4 CABLE BARRIER SYSTEM

INSTALLATION GUIDE

Gibraltar Cable Barrier System 1208 Houston Clinton Dr. Burnet, Texas 78611 +1 (512) 715-0808 • www.gibraltarglobal.com

[Note to Installer: Refer to Contract Plans and Documents for Specific Details]

The Gibraltar Cable Barrier Systems are covered by one or more of the following patents: U.S. Patent No(s).: 7,364,137; 7,398,960; and 7,401,996. Other U.S. and International patents are pending



INSTALLATION GUIDE

TABLE OF CONTENTS

3

I WELCOME

II. MASH16 CHECKLIST

II. SYSTEM COMPONENTS

III. EQUIPMENT / TOOLS REQUIRED

5

IV. TERMINAL SECTION INSTALLATION

10-14

V. LONGITUDINAL SECTION INSTALLATION

- A. Socketed System
- B. Installing Cable
- C. Installing Hairpins and Lockplates
- D. Installing Cable SpliceTurnbuckles

15 VI. REPAIRS & MAINTENANCE

16

VII. TECHNICAL & SALES SUPPORT

VERSION: [9.0] UPDATED: [APRIL 2021]





I. Welcome

Welcome to the Gibraltar Cable Barrier System Installation and Maintenance Guide. This guide is for your use when installing Gibraltar's cable barrier system. This installation guide is for standard cable barrier installations.

Before You Begin:

Check and confirm packing list contents. Please report any errors or shortages immediately to Gibraltar at 1 (833) 715-0810 or 512-715-0808.

II. System Installation & Components

- A. Cable Barrier System Longitudinal Section Layout
- B. Cable Barrier System Terminal Section Layout
- C. Cable Interchanging
- D. Parts Lists

III. Equipment/Tools Required

- IV. Auger (for Socketed Line Post and Terminal Post foundations)
- V. Auger (Anchor Post foundation)
- VI. Post Driver (for Driven Post option)
- VII. Adjustable Wrench (2)
- VIII. Tension Meter
- IX. Utility Trailer (rigged for Wire Rope Spools)
- X. Flathead Screwdrivers (2)
- XI. 3 Ton (6000 lb.) Chain Hoist (6 Ton hoist may be required in cold climates)
- XII. Cable Grabbers (2)
- XIII. Vice Grips (large enough to fit over 3/4in cable) or 3/4in cable clamps
- XIV. Thermometer



GIBRALTAR MASH 2016 INSPECTION CHECKLIST

TERMINAL SECTION

Ensure the anchor post is centered in the hole on stringline, the anchor plate is set no more than 1" above grade and is set plumb using the cable release post.

Ensure terminal post #1 leans 1 $\frac{1}{4}$ " every 12" out of plumb towards the anchor and the top of the socket is at grade (p.7).

Ensure the second terminal post socket is set plumb and the top is set at grade. Ensure the terminal posts "open" side is away from the center line (p. 7), and the j-bolts are installed.

Ensure the cables are set in each j-bolt and on the 2nd terminal post, the top cable is resting on the 3rd cable (p. 7)

Ensure all fittings are installed correctly with the wedge correctly installed in the acorn fitting (p. 8 & 13).

LENGTH OF NEED

Ensure line post sockets are set plumb, with the short side of socket on the stringline and the top is flush with grade. A post can be used to make sure the socket is plumb.

Ensure posts are set in the sockets with the open C is facing the cables, and the hairpin and lockplates are installed in each post.

The posts in the terminal and the next five posts after the terminal must alternate on sides of cable, the remaining posts should alternate throughout the system. In some cases, it is not possible to have all posts on alternating sides of cable, 3 posts on the same side of cable is acceptable in these situations, contact Gibraltar if this occurs more than once in a single run.

Ensure each cable of each run has at least one set of cable splice turnbuckles (CSTB). The turnbuckles should be no greater than 2,000 ft apart. Ensure the CSTBs on the top two cables are separated and are not touching each other.

Ensure the cables are properly installed in each post utilizing the hairpin and lockplate design. The top two cables should alternate being in the top hoop of the hairpin and being set on top of it. There should be no twisting of the cables from post to post. (p. 12)

Ensure the cables are all tensioned within 10% of the tension chart shown on the drawings and are noted in a tension log.

IV. Terminal Section Installation

The Gibraltar cable barrier system shall be installed in standard compacted soil. Soil must be well drained.

Step 1. Establish and verify starting point of cable barrier system in cooperation with designated Transportation Department representative. If the starting point is at the beginning of the length of need/longitudinal section and not the terminal section, then add 27ft-6in to the starting point.

Step 2. Establish the cable barrier center line. Mark the position/s of the Anchor Post/s (Part AP-MASH-4CBL) and ter-minal posts as per manufacturer's plans.

NOTE: when excavating, each hole is offset 2in from the center line, on alternating sides of the cable barrier fence line.



Long side of Socket

Short Side of Socket

Place Socket in terminal post holes. Place the 3in (short) side of the socket directly on the string line, parallel to the cable barrier center line.

Note: Some sockets have a welded seam along the inside of the 3in side of the socket.

NOTE: In terminal posthole No. 1, the socket must be <u>angled toward the anchor 1¼in in 12in out of</u> <u>plumb.</u>

Post out of plumb tolerance: The sockets should be set plumb, or the posts driven plumb. An acceptable tolerance out of plumb is 3in at the top of the post. This tolerance is aesthetic only and does not affect the performance of the system.

Step 3. Center and auger the 24in diameter by 10ft minimum deep hole for the embedded Anchor Post (Part AP-MASH-4CBL). Hole must be in-line with the cable barrier center line.

NOTE: Sizes of footings may vary depending upon state specifications and soil conditions.

Step 4. Place anchor post rebar cage (provided by installer) into the hole and pour concrete to within 2ft of top, then stab Anchor Post (Part AP-MASH-4CBL) in place plumb. Finish pouring concrete to grade. The center of the Anchor Post should be centered in the hole and set in-line with the cable barrier string line. **NOTE: The center of the Anchor Post must be centered in-line with the cable barrier center line.**

Set the lowest edge of the top plate of the Anchor Post one inch (1in) above grade facing opposite from the cable barrier system.



NOTE: The Gibraltar terminal is designed for standard soil special depths and anchor designs are used for alternative soil types. The soil should be well drained and compacted. If poor soil conditions are encountered it is important that you contact your transportation agency for any special criteria for weak soil conditions. In some cases it may require that a qualified engineer be consulted for soil investigation and engineering.

Allow concrete to set for a minimum of 72 hours before tensioning cables.



Set the socket for Terminal Post No. 1 (Part TP1-4) angled towards Anchor Post 1¼in in 12in out of plumb.

The angle of the socket for Terminal Post No. 1 (Part TP1-4) may be determined by tilting the socket 1¼ in in 12 in out of plumb, or 5/8 in in 6 in out of plumb. Add specified concrete.

Step 5. Place Terminal Post TP1-4 and Terminal Post TP4-4, in their respective sockets. For each Terminal Post, place the "open" side of the C-Section post away from the center line. Place the three (3) or four (4) J-Bolts (Part J-BLT) as required in each terminal post.





3 J-Bolts
(Part TP4-4)

Set Cable Release Post (Part CRP-MASH-4CBL) on top of Anchor Post (Part AP-MASH-4CBL).





Step 6. Connect the four (4) cables to the Anchor Terminal Fittings (Part ATF-END) by inserting the cable ends into the "acorn" shaped casting of the Anchor Terminal Fittings (Part ATF-END). Using two flathead screwdrivers, separate the three strands of the cable at the end within the acorn shaped casting.

Place and insert the triangular wedge between the cable strands. The triangular wedge must point toward the cable. The strands will fit within the acorn channels. Remove the screwdrivers and drive the wedge into the cable, at least a 1/2in past the end of the cable. Next, take a hammer and hit the end of the acorn casting away from the cable in order to securely set the cable into the casting. Then place the nut inside the opening of the Anchor Terminal Fitting (Part ATF) and thread onto the bolts. *Refer to video on website for further demonstration. (www.gibraltarglobal.com)

Connect the Anchor Terminal Fittings (Part ATF-END) with cable attached into the Anchor Post.



V. Longitudinal Section Installation

The Gibraltar cable barrier system is to be installed as a median or roadside barrier with a slope of 4:1 or flatter without depressions, obstructions, etc, that may influence or have an effect on vehicle stability or trajectory. Site grading or fill may be required where topographical issues would prevent the cable height to be inconsistent with tested and proper design heights.

The Gibraltar MASH16 TL-4 cable barrier system is acceptable as a TL-3 traffic barrier when placed no farther than 4ft down a 4:1 slope (for adjacent traffic impacts) and no closer than 8ft from the ditch bottom for opposite side impacts.

A. Socketed System

Step 1 - For a socketed system, space the line posts and dig the footings as shown on the plans. Center the auger 2in off the center line, alternating on each side of the center line. All line post sockets should be set plumb.

Rock Clause: Where solid rock is encountered:

- For a socketed post, continue digging hole, 15in deep into rock or to the required plan depth whichever comes first.
- For a driven post, drill a 4in diameter hole 18in deep into rock or to the required plan depth, whichever comes first.
- For an Anchor Post, continue digging hole, 30in deep into rock or to the required plan depth, whichever comes first.

Step 2. Place the appropriate Socket in each hole and set plumb. Place the 3in side of the socket directly on the string line and parallel to the center line of the cable barrier fence.





Step 3. Place the Line Post (4-LNP-S) into socket. Alternate posts with the "open" seam of the C-section post facing the center line.

B. Installing Cable

For the installation of all systems, we recommend that you utilize a utility trailer with the capacity to spool and dispense all four cables simultaneously. (NOTE: Each spool contains 2,000 linear feet of cable and weighs approximately 1,900 lbs per spool.) Special arrangements can be made for more or less cable per spool.

It is preferable to use a cable trailer with a GVW of 20,000 - 24,000 lb. capacity, capable of holding a minimum of six (6) spools of cable at one time. Six (6) spools of cable, along with enough related posts and parts weigh approximately 18,000 lbs.



<u>Special Note: When factory swaged cable is required, call Gibraltar for special instructions on</u> <u>unspooling, stringing and connecting swaged cable.</u>

C. Installing Hairpins (Part 4-HPIN Alum) and Lockplates (Part 4-Lock)

Step 1. Insert the bottom end of the appropriate Hairpin into the C-section channel located at the top of the open line post by holding the angled handle of the hairpin.

Step 2. Lay the three bottom cables in molded/indented slots of the hairpin and place the hairpin on top of the back side of post, then drop the appropriate Lockplate into place on the inside of the line post. Place the fourth cable on top of the hairpin, see Cable Interchanging Drawing below and in Appendix.

<u>Cable Height Tolerances</u>: The bottom cable should be 20in above ground grade, +/- 1in tolerance is allowed, at the socket or post location.







Installed Hairpin and Lockplate

Geometric Features (Depressions)

When the cable barrier installation goes through a depression and tension on the cables begins to pull the hairpin and lockplate up and out of the top of the C-section post, attach the lockplate to the C-section post with a self-tapping set screw (size #12 by ¾in). Also, if necessary, with a socketed post system, it may be necessary to run a self-tapping screw in between the post and the socket. (See photos below.)



D. Installing Cable Splice Turnbuckles

Step 1. At every 2,000ft (ensure at least one set of turnbuckles per run), cut the cable and place a Cable Splice Turnbuckle (Part CSTB) between the cable sections. Connect the cable to the Cable Splice Turnbuckle (Part CSTB) by inserting the end of the cable into the "acorn" shaped casting of the cable splice turnbuckle.

Step 2. Using two flathead screwdrivers, separate the three strands of cable at the cable ends that go into the acorn shaped casting. Place the triangular wedge spike pointing toward the cable and insert the wedge between the strands. The strands will fit within the acorn channels. Remove the screwdrivers, rotate the acorn up over the wedge and drive the wedge at least a 1/2in past the end of the cable. Take a hammer and hit the end of the acorn casting away from the cable, seating the cable into the casting.







Correct Installation of Wedge

Correct Installation of Wedge

Note: When connecting the cable, make sure that all of the turnbuckle bolt threads are available for tightening by the turnbuckles

Step 3. Place the nut in the opening of the Cable Splice Turnbuckle (Part CSTB) and thread the nut onto the bolt. **NOTE: The Cable Splice Turnbuckle (Part CSTB) should be positioned between line posts, and not directly on a line post.** When cutting the cable, cut just past a line post so that when tension is applied the turnbuckle will be between two posts. If unavoidable, call for additional parts.

Step 4. When connecting cables, use a chain hoist or wench appropriate for the tension needed. If connecting cables in the middle of a run, use two cable jacks and a chain hoist. Tension the cable to the approximate tension shown on the plans, relative to the current temperature at the time of installation.

Step 5. Next, cut and connect the cable by attaching an anchor terminal fitting to the cable, then place all anchor terminal fittings into the slots of the anchor post. (See Step 6, page 7 & 8 for photo detail.) <u>NOTE:</u> <u>Placement of the anchor terminal fitting (Part ATF) in the anchor Post slots is not a critical placement issue, (for example, the top cable in the middle slot).</u>

Step 6. When placing final tension on cables (in accordance with the tensioning chart located on the plans) adjust each turnbuckle as needed; log the current date, time, temperature and amount of tension by utilizing the Tension Meter (Part T-MTR).



NOTE: Once a section is completed, each section should be checked from beginning to end for correct tension and adjustments, if needed. Once you have reached the specified tension required, take a hammer and screwdriver and "ping" the threads just enough so that the turnbuckle will not "back off", thus causing a loss of tension.

VI. <u>Repairs and Maintenance</u>

Once the system takes a hit, repairs can be made quickly and easily. Check for any damaged parts within the length of need and/or within the terminal section. All damaged parts must be replaced. The cable can take multiple hits, but when a single strand is broken, cut out the damaged section of cable and splice in a new cable using turnbuckles.

Replacing damaged posts:

To replace a damaged, socketed post when "wedged" in the socket, use a come-along and a straight post as a "pull post" to lift and remove the damaged post out of the socket. Place a new post in the socket. Once all of the damaged posts are replaced, attach the cables with new hairpins and lockplates.

If the terminal section is hit, replace any and all damaged parts and re-install as per terminal section installation instructions.

If a vehicle becomes entangled:

Should a vehicle become entangled in a cable and cannot be removed from the system, as a last resort, the turnbuckle may be cut to untangle the vehicle. Use extreme caution when cutting the turnbuckle. Have all personnel stand clear of the system. Whoever is cutting the turnbuckle should stand perpendicular to the cable and cut with a quick saw. Note that it is important to realize that if you cut the turnbuckle you can cause more damage to the system. Therefore, cutting a turnbuckle should be used only as a last resort and extreme caution should be exercised. See last page in this manual for recommendations.

Re-tensioning cable:

Go to the nearest turnbuckle and attach the tension meter to the first cable you will be tightening. Adjust the turnbuckle until the tension on the cable matches the tension chart, based on the current temperature. Repeat this process for the other two cables.

Note: If the system takes a hit within 300ft of a turnbuckle, adjusting the turnbuckles at that one location should be sufficient. However, if the system takes a hit midway between turnbuckle splices, (approximately 1,000ft from a turnbuckle), re-tensioning should be performed at turnbuckles on each side of the hit.



CONTACT US

WWW.GIBRALTARGLOBAL.COM

VII. TECHNICAL SUPPORT

Gibraltar Cable Barriers 1208 Houston Clinton Dr. Burnet, TX 78611 833-715-0810 (toll free) 512-715-0808 (office) 512-715-0811 (fax) info@gibraltarglobal.com

Page 16





1. For additional information contact Gibraltar, Inc. at 1-833-715-0810 or see the

The Cable Barrier System shall be installed on shoulders or on medians with slopes of 6:1 or flatter. If installed on slopes steeper than 6:1 up to 4:1 the TL-4 system performs as a TL-3 and Gibraltar must be contacted for various

6.A. For socketed post, continue digging 12" diameter, 15" deep into rock or

6.B. For driven post, core drill a 4" diameter hole 18" deep into rock or the

6.C. For Anchor post, continue digging 24" diameter, 30" deep into rock or

7. The Gibraltar cable barrier system shall be installed in standard compacted soil.

9.A. Without mowstrip, 36" Deep x 12" diameter foundations with #3 rebar ring x 8" diameter with two #4 rebar vertical bars 30" long or 30"

9.B. With 4" minimum depth hot mix asphalt, 30" deep x 12" diameter foundations with #3 rebar ring x 8" diameter with two #4 rebar vertical

9.C. With 3" minimum depth concrete mowstrip, 24" deep x 12" diameter

Chart*				
-10 °F	8600			
0 °F	8200			
10 °F	7800			
20 °F	7400			
30 °F	7000			
40 °F	6600			
50 °F	6200			
60 °F	5800			
70 °F	5400			
80 °F	5000			
90 °F	4600			
100 °F	4200			
110 °F	3800			

Cable Tension

*Allowable Deviation from Chart +/- 10%

PROPRIETARY TO GIBRALTAR MASH 2016 TL4

Gibraltar Cable Barrier Systems					
cale:	Date:				
NTS	8-26-21				
ayout:	Drafter:				
ANSI B	BH				









ORDER FORM COVERSHEET

1208 Houston Clinton Dr., Burnet, Texas 78611

(512) 715-0808 | Toll-Free: (833) 715-0810 | Fax: (512) 715-0811

ORDERS@GIBRALTARGLOBAL.COM

ALL ORDERS MUST HAVE A COMPLETED COVER SHEET TO PROCESS WITHOUT ANY DELAYS **PLEASE ALLOW 3-5 BUSINESS DAYS TO PROCESS ORDERS PLUS SHIPPING/TRANSIT TIME **

DATE:	PLEASE CHECK ALL APPILICABLE BOXES	QUOTE NEEDED FOR:	MATERIALS	FREIGHT
COMPANY NAME:				
CONTACT NAME:				
PHONE NUMBER:				
FAX NUMBER:				
EMAIL:				

* PLEASE INCLUDE YOUR EMAIL ADDRESS SO WE CAN SEND YOU AN ORDER CONFIRMATION FOR APPROVAL PRIOR TO SHIPPING (BE SURE YOUR EMAIL ADDRESS IS LEGIBLE)

PO NUMBER:	COUNTY & STATE:
	COONTI & STATE.

SHIPPING ADDRESS:	BILLING ADDRESS:		

Shipping Contact:	RECEIVING HOURS:	
Shipping Phone:	RECEIVING HOURS:	

*** PLEASE LIST ANY SPECIAL DELIVERY NEEDS BELOW ie. CALL AHEAD REQUIREMENTS, LIFT GATE REQUIRED, LIMITED ACCESS, ETC.***

Notes:

FOR QUESTIONS REGARDING ORDERS PLEASE CONTACT JOHN JANSEN AT (512) 715-0808. JJANSEN@GIBRALTARGLOBAL.COM

FOR TECHNICAL QUESTIONS CONTACT INFO@GIBRALTARGLOBAL.COM

**PRICES DO NOT INCLUDE SHIPPING & HANDLING CHARGES **

**PLEASE NOTE IF FREIGHT COSTS NEED TO BE INCLUDED IN THE PRICE OF MATERIALS **



TO ORDER REPLACEMENT PARTS, CONTACT:

Gibraltar Global LLC 1208 Houston Clinton DR Burnet, TX 78611 Toll Free: (833) 715-0810 Office:(512) 715-0808

Email: ORDERS@gibraltarglobal.com Fax: (512) 715-0810

SYSTEM TYPE: MASH16 TL4

PART #	ITEM / DESCRIPTION	PRICE UNIT QUANTITY		QUANTITY	EXTENDED AMT
4-HPIN ALUM	3 Cable Alum HPIN	EA			
4-LOCK	TL-4 Lockplate		EA		
U-LOCK	U-Bolt Lockplate Assembly (Consists of Lockplate and 3 U-blts)		SET		
4-LNP-S	TL-4 Line Post / Socketed (57")		EA		
4-LNP-D	TL-4 Line Post / Driven (84")		EA		
AP-MASH-4CBL	MASH Anchor Post		EA		
SOCK-S	15" Socket 4" x 3" - 15" long w/ (4) 16" bars		EA		
SOCK-P	4x3x15" Plastic Socket		EA		
TUBE-PL	15" Tube Socket 15" 4" x 3" with welded plate		EA		
TUBE-D	42" Driven Socket 4" x 3" with Post Stop at 15"		EA		
CRP-MASH-4CBI	MASH Cable Release Post	EA			
TKW	Terminal Keeper Wire (12-Ga.x 12" long)		EA		
TP1-4	Terminal Post No.1/ Weak 48" (4-Hole)	EA			
TP4-4	Terminal Post No.4/ Standard 57" (3-Hole)	EA			
J-BLT	J-Bolt (3/4")		EA		
ATF-1"	Anchor Terminal Fitting (1") Includes Turnbuckle		EA		
ATF-End 1"	Anchor Terminal Fitting End 1 18" x 1" Rod and Acorn		EA		
CSTB-1"	Cable Splice Turnbuckle (3/4") Open Body		EA		
TORP	"Torpedo" Splice		EA		
ACORN	Acorn		EA		
WEDGE	Wedge For Acorn		EA		
DLN	Delineator / Reflective Object Marker - Specify Yellow or White		EA		
CBL-PRE	Pre-stretched Cable (3/4"Guardrail Cable)*[See Note 1]		LF		
EXCL-CAP	Excluder Cap - Post Base		EA		
CAP	Post Cap Sleeve - Post Top		EA		
T-MTR	Tension Meter with Case *[See Note 2]		EA		
PPE	NOW OFFERING PERSONAL PROTECTION EQUIPMENT	Call for details			etails
TRAINING	Installation and Repair Training *[See Note 3]	Call for details			etails
			-		
	Cable sold as a complete 2000' spool only (unless remnant pieces are available) Gibraltar Global recommends that the tension of the cables be checked after every	~			
NOTE-2	repair	SI	IPPING		
NOTE-3	and certified by Gibraltar Global * Please call for more information	ORDER TOTAL			

Cable Tensioning Chart

The cable shall be tensioned immediately after initial installation. Tension shall be rechecked and adjusted, if necessary, at least three to five days after initial tensioning on cable system. A tension log form shall be completed showing the time, date, location, temperature and final tension reading, signed by the person performing the tensioning, and furnished to the engineer upon completion of the work. This form shall also include the system manufacturer's recommended tension chart.

DATE	TIME	LOCATION	AMBIENT TEMPERATURE	INITIAL TENSION READING	FINAL TENSION READING	SIGNATURE



Best Practices to Remove Vehicles from the Cable Barrier System

- Use caution and best judgment when approaching a hit where the vehicle is still engaged with the cables, there could be an unstable situation with the cable.
- Keep "non emergency" personnel away from the cable system
- Methods to release tension in the system
 - If not deeply entangled, go upstream and downstream of the accident for 75' to 100' removing lock plates and hairpins to release cables (cables are not attached to the posts) until the weight of the cable overcomes the tension introducing some additional slack and eventually allowing the cables to lie on the ground.
 - Go to the anchor unit and release the tension by pushing over the Cable Release Post with a vehicle bumper, making sure all personnel stand clear of the anchor section.
 - Go upstream or downstream to the nearest cable splice turnbuckle, which are spaced approximately 1000 ft. apart and loosen them a few turns. You will need two crescent wrenches and a long screwdriver/long bar, the longer the wrench the better the leverage.
- Methods to release the vehicle
 - If a vehicle is "entangled" in the cables, first pull the vehicle back towards the centerline of the cable barrier to take out the lateral force of the cable, and then pull the vehicle out the same way it entered.
 - A tow truck should be able to lift most vehicles off the cables if the vehicle happens to end up "straddling" a cable.
- Only cut a turnbuckle body or cable if it is a life or death situation and the car needs to be removed immediately.
 - Ask all on-lookers and non-essential personnel to stand clear of the system to prevent injuries from backlash when cutting. Because of the cable's weight (1 pound/ft), the cable should fall down as it retracts.
 - Ensure that no one is holding the cables near a post as their hand could be pinched upon cutting the cable.
 - Cut the turnbuckle body or cable in between two line posts, 250 to 300 feet away from the vehicle and perpendicular to the cable system.

*** Knocking over the Cable Release Post or cutting a turnbuckle/cable will cause the entire system, from anchor to anchor, to be disabled. Until the system is repaired, the system will lose **all** of its effectiveness to prevent any future accidents and it may allow the next vehicle to get through the system and into oncoming traffic. ***

If you have any questions about the system during an accident, contact Gibraltar Cable Barrier Systems at 833-715-0810 and ask for Jay Winn, Bryan Hoefling or Ron Faulkenberry.